## C\*MET ANTENNA

# MODEL GP-98

High Gain Triple band Ground Plane Antenna for 144, 430 & 1200MHz

# **Instruction Manual**

Lower Element w/ FRP outershell - 1
 Upper Element w/ FRP outershell - 1

- 3

- 1

- 1

- 1

- 1

- 2

- 1

2

2

Thank you for purchasing our products.

### For your safety:

Read this manual carefully for proper handling and operation before using. Keep this manual in a safe place for future reference.

### [Features]

- •Low-Loss and High Gain, based on SLC, Super-Linear-Converter.
- •GP-98 is Wide-Band, and requires no Frequency adjustment.
- •Heavy-duty fiberglass guarantees perfect water/pollution-proof and prevents OSB.
- •Enjoy Triple-Band Communication with COMET Triplexer, CF-431 and/or CF-4310.

### [Specifications]

Frequency: 144, 430 & 1200 MHz Gain: 144MHz / 6.5 dBi, 430MHz / 8.6 dBi 1200MHz / 13.5dBi

 $\begin{array}{l} \text{Impedance}: 50~\Omega \\ \text{VSWR}: 1.5~\text{or less} \\ \text{Length}: 2.94~\text{m} \end{array}$ 

Max Input Power: 144MHz / 300W (SSB) 430 & 1200MHz / 200W (SSB)

Weight: 1.5 kg Max Wind Survival: 40m/sec Mounting Mast Diameter: Φ30-62mm Connector: M-Jack or N-Jack

Radial

### [How To Assemble]

1. How to assemble/mount

Connect the Lower Element and the Upper Element, using the Hex Wrench. (See Fig. 1) Put the Upper Pipe into the Lower Pipe. Then, assemble the ABS Joint with rubber washer.

[Parts List]-

3. Radial w/ Hex. nut

6. Mount support pipe

10. Hex. key Wrench

11. Hollow-set screw M3x3

5. Mount bracket

4. Power feeding section


7. Lock bolt w/ sp.washer M6


8. Hex.bolt w/ sp.washer M6x30

9. U-Bolt w/sp.washer & Hex.nut

- 2. Assemble three radials. Fasten radial-lock Nuts securely with spanner etc....(See Fig. 2)
- 3. Put two mount brackets on the mount support pipe. Pass the coax cable through the pipe, and attach it to power feeding section. Be sure to fasten hex bolts firmly. Then, attach support pipe onto the antenna. (See Fig. 3)
- 4. Mount all assembled antennas on your mast. This antenna is so long. Keep your eyes on balance of this antenna and use as strong mast as you can, between 30 to 62mm dia.

### \*Make sure to use low loss coax cable.






Note: For long-term use, water-proofing with glue, self-fusing tape, and/or vinyl tape is highly recommended.

# Insert screw Spanner Fasten Mount support pipe Lock nut

### ◆Mount Bracket & U-Bolt



### COMET CO.,LTD.

4-18-2, Tsuji, Minami-ku, Saitama-shi, Saitama-Pref, 336-0026, JAPAN

TEL: 81-48-839-3131 / FAX: 81-48-839-3136 URL: http://www.comet-ant.co.jp/english

### Precautions for using

- This antenna is only for ham radio. Do not use this for other purposes.
- Operation outside the specification might damage the antenna.
- Adjust the antenna correctly. Elevated SWR could damage the antenna.
- Never attempt to modify or fix the antenna by yourself.
- Do not touch the antenna while transmitting.
  - Specifications or appearance is subject to change without notice.